

# Assembly Instruction


## Vika Pendant




Vika pendant (1x)




Ceiling bracket (2x)  
(T24 profile)



Ceiling cup (1x)




Roof bracket (1x)




3m Wire with ball (2x)


1.




2.



3.






A. Insert the wire into the gripper. Always insert the wire through the pin unless otherwise stated.



B. Adjust the gripper up. When you let go of the gripper it will automatically lock itself on the wire.




C. Press the pin and adjust down. When you press the pin the lock opens and the gripper slides freely up and down the wire. Release the pin to lock the gripper again.




A. Direction of wire and gripper must be in a straight line

B. The wire must be inserted all the way through the gripper and protrude at least 5 mm from the bottom.



4.



Turn the lamp so the bright light is down

Dim light up

Bright light down

B-B

# Care instructions

To maintain the color and appearance of the Vika, the product should be vacuum cleaned regularly with a soft nozzle.

Stain removal, dab or wipe gently with a damp cloth.